



**Service information**

**Reference no.: SDA\_101553**

**Symptom**

After boiler replacement appliance starts heating immediately

**Cure**

**INFO:**

When an appliance comes in and the boiler has no function (no power measured), the boiler needs to be replaced. It can occur that after replacement the boiler starts heating automatically, even without the unit being switched on. This is caused by a defective boiler triac, this defect may have been caused by a short circuit in the boiler's heating element. The short circuit in the heating element does not automatically mean the boiler can be identified as defective.

**CURE:**

First replace the boiler, when the unit starts heating without any user interaction, replace the PCBA as well.

**REMARK:**

25-09-2013: Initial version.