



**Service information**

**Reference no.: SDA\_102197**

**Symptom**

On/off button blinking fast / Watercontainer not detected

**Cure**

**INFO:**

Any appliance returned with a complaint regarding "on/off button blinking fast" the float in the water container must be checked for signs of rust (oxidation), when that is the case the water container needs to be replaced.

The magnet in the float of the water container can start to rust. A rusting magnet is heavier than a non-rusting magnet. At a certain point in time the weight of the float will be so high, it will no longer float to the top position. During transport from the consumer to the repair center the water in the float will dry up, making it function properly when it arrives at Service. After a period of time the float will start to sink again, losing its function, therefore: signs of rust = new water container.

Please see below an overview of Water containers, with rusting floats.



**CURE:**  
Replace the watercontainer

**REMARKS:**  
- 25-10-2013: Initial version  
- 13-11-2013: Textual improvements GC