Reference no.: SDA_112015



Service information

Symptom

Battery doesnot charge or runs after charging a few minutes

Cure

SYMPTOM: Battery does not charge or no function or other electronics issues

In case of repair related to "no charging, no function or other electronics issues", due to the unavailability of battery & PCBA

parts the preferred service scenario is to exchange the FC8700/ FC8710 robot with an FC8810 Robot

REMARK: This is a Service Policy for the FC8700 and FC8710 models $\underline{\text{till further notice}}$

At the moment when the new components can be supplied, the S/C will be updated with the available codes and leadtime.

In case there is stock of the below components, the stock can be scrapped: 4322 006 22901 4322 006 22911 4322 006 23671 4322 006 23681