



Service information

Reference no.: SDA_95571

Symptom

Side brushes are not working anymore or are turning very slowly

Cure

SYMPTOM: Side brushes of the robot cleaner are not rotating anymore or are rotating slower.

CURE: To prevent that consumers will face this problem, the next components need to be replaced :

Right side brush set

code 9965 100 53906

pos.nr. 16 on Service Manual

Left side brush set

code 9965 100 53916

pos.nr. 20 on Service Manual



Pos. nr. 20 looks the same only then mirrored

REMARK (changed dated 6-11-2012) :

This repair needs to be done at **all appliances** which are on stock, produced in wk. 1223 till wk. 1230.

Appliances which have been produced after wk. 1230 do not have this problem anymore.

If consumers are already in possession of appliances which show this problem, also same repair as indicated above needs to be done.