

Service
Service
Service



Philips Domestic Appliances and Personal Care

Service Manual

PRODUCT INFORMATION

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

Charge/Discharge indication

- Charging : Blue LED lights up during charging
- Battery Low : Blue LED blinks fast during discharge after battery pack voltage drops below:
4.2 V $\pm$ 0.2V (NiCd)
4.5 V $\pm$ 0.2V (NiMH)

TECHNICAL INFORMATION

- Charger AC / DC (NiCd) : 230 V / 9V DC - 200 mA or
: 110 V / 9V DC - 200 mA
- (NiMH) : 230 V / 9V DC - 250 mA
- Rechargeable batteries : 4x NiCd - 1700 mAh or
: 4x NiMH - 2000 mAh
- Run time : 50 min. (NiCd)
: 58 min. (NiMH)
- Charging time : 16 - 18 hours
- Charge/BLI indicator : LED
- Charging via charging base or directly with charger possible.
- Application environment : Dry
- Dust capacity : 210 ml
- Weight : 2 Kg

REPAIR INSTRUCTIONS

- No specific issues

ASSEMBLY & DISASSEMBLY ADVICE


- No specific issues

OPTIONAL (accessories)

- No specific issues

PARTS LIST & EXPLODED VIEW

FC6125



Pos	Service code	Description
1	9965 000 32142	Charging base
2	9965 000 32143	Complete dirt tray
3	9965 000 32145	Charger WE
	9965 000 32144	Charger Swiss
	9965 000 37498	Charger Taiwan 110 V
	9965 000 38116	Charger PRC
	9965 000 38117	Charger UK/Hongkong
4	9965 000 32147	Complete sweeper base (NiCd)
	9965 000 32146	Complete sweeper base (NiMH)
5	9965 000 32148	Front wheels kit

Pos	Service code	Description
6	9965 000 32149	Transparent front cover
7	9965 000 32150	Roller brush
8	9965 000 32151	Retainer
9	9965 000 32152	Upper Handle Ass'y
10	9965 000 32153	Telescopic tube ass'y
11	9965 000 32154	Lower tube ass'y
12	9965 000 32155	Rear wheels kit
13	9965 000 32157	Battery pack (NiCd)
	9965 000 32156	Battery pack (NiMH)
14	9965 000 32158	Battery pack lid