

HP6341/00



HP6342/00

Philips Consumer Lifestyle

Version: A

Service Manual

PRODUCT INFORMATION

Lady shaver for women to shave following zones:

- Shave legs (wet and dry use)
- Shave armpits (wet and dry use)
- Shave and trim bikini zone (wet and dry use)
- Home use in bathroom

Safety

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

TECHNICAL INFORMATION

- | | |
|-------------------------------|--|
| - Speeds | : Single speed |
| - Batteries | : 2 x AA 1,5 V Alkaline |
| - Shaving head | : SFR cutter (Straight Foil Round) with protection, efficiency cap and comb |
| - Release System shaving head | : 2 side buttons on body |
| - Efficiency cap | : Plastic cap which should give the consumer feedback about proper application angle |
| - Protection cap | : Plastic cap to protect the foil from dirt |
| - Runtime | : 40 minutes with new alkaline batteries from Philips Power life |
| - On/off switch | : Slider |
| - Wet & dry | : Water proof device for wet application |

DISASSEMBLY- AND RE-ASSEMBLY ADVISE

- No specific issues.

REPAIR INSTRUCTION

- This is a replacement appliance.
For this Shaver only the parts shown in the exploded view will be supplied.

Hints for repairs:

- No specific issues.

OPTIONAL (accessories)


- No specific issues.

PARTS LIST & EXPLODED VIEW

HP6341/00
HP6342/00



Pos	Service code	Description	HP6341	HP6342
1	4203 035 94901	Protecting cap	X	X
2	4203 035 94911	Shaving unit	X	
3	4203 035 94921	Shaving unit		X
4	4203 035 94931	Shaving head	X	X
5	4203 035 94941	3 mm trimming comb		X
6	4203 035 94951	Efficiency cap		X
7	4203 035 94961	Battery compartment cover	X	
8	4203 035 94971	Battery compartment cover		X
9	4203 035 94981	Pouch (not shown)		X
10	4222 036 02770	Cleaning Brush (Philishave) black	X	X

 = changed