# **Promopack Epilator & Bikini Trimmer**







HP6530/30

#### **Philips Consumer Lifestyle**

# **Service Manual**

#### **PRODUCT INFORMATION**

Epilator HP6507/30

#### General

- Mains operated Epilator

## Bikini Trimmer HP6371/00

#### **Features**

Wet & dry use : In and out of the showerRechargeable : Charge lasts up to 60 minutes

# Accessories

- Precise and gentle trimmer
- Hygienic trimming comb

#### Safety

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

#### **TECHNICAL INFORMATION**

#### Epilator HP6507/30

- Type : AC (mains operated)
- RPM : speed 1 - 2000 rpm
speed 2 - 2400 rpm

- Number of catching points: 20

- Pulling actions / second : speed 1 - 633,

speed 2 - 733

- Voltage : Pri. : 110 - 220 V - AC

: Sec. : 13V - 400 mA : 50 - 60 Hz

- Frequency : 50 - 60 - Power consumption : 7,5 W

## **DISASSEMBLY- AND RE-ASSEMBLY ADVISE**

- No specific issues.

## **REPAIR INSTRUCTION**

- Only the parts shown in the exploded view will be supplied.

# **OPTIONAL** (accessories)

- No specific issues.

Published by Philips Consumer Lifestyle


Printed in the Netherlands


© Copyright reserved

Subject to modification




# **HP6530/30**













Pos	Service code	Description	Model-Nr.
1 2 3 4 5	4203 035 86990 4203 035 87130 4822 479 30183 4203 035 51810 4203 035 50900	Efficiency Massage Cap Epihead Assy HP6507/30 Brush (Philishave) Black Adapter EU HP6507/30 Adapter EU HP6371/00	SSW-2082EU
6 7	4203 035 84640 4203 035 84490	Trimmer Accessory Trimmer Comb	