



Service information

Reference no.: GDA_112100

Symptom

Garment Care : Pump Shock Therapy

Cure

This is a General information for New Pump parts received in Service Centre!

For New Pump spare part received , please performance the following test before assemble into the system.

This will help to put pump in pre-condition state before install into the system.

After replacement of the pump and we detect it's not pumping water, the process is :

- connecting a water-filled syringe on the input pump
- injecting a little into the pump using the syringe
- power on the Device
- Use a Magnet to magnetize the hall sensor to simulate the water container present
- water is pushed simultaneously with the syringe when the pump is working

Affected new parts are the pumps for the GC66xx,GC70XX, GC76XX, GC86xx and the GC9540. These must be blown only with water or air pressure. With the GC66xx and GC9540 you can do this from the outside about the water tank or water inflow, with the GC86xx the device must be opened in addition.

Setup configuration:



Syringe:

