



Service information

Reference no.: SDA_101877

Symptom

Ty-wraps to be used

Cure

INFO:

We now have Ty-wraps on stock, both for Hoses as well as for the Boiler.

CURE:

Please use: 422224450680 for fixing hoses in Senseo appliances. Please apply a force of 115N, with a suitable tool.

Please use: 422224450692 for fixing the boiler in Senseo Quadrante and Latt Duo appliances (HD786x, HD7855, HD7856 and HD7857). Please apply minimal force to close (only hand-tight).

REMARKS:

10-10-2013: Initial version