



Service information

Reference no.: SDA_102628

Symptom

Mandatory: insert sheet cleaning coffee powder duct odea

Cure

INFO:

The machine may not working properly because the coffee powder duct (shown by the arrow in Image 1) become clogged.

CURE:

From S/N TW90134867769 the new additional sheet code 421946010581 with the instruction for cleaning coffee powder duct has been inserted.

In all Odea machines that return to workshop for any reason up to S/N TW90134867768, insert the additional sheet code 421946010581 that you find in the attached file.

Image 1

