

Reference no.: SDA\_85092



## Service information

## **Symptom**

Aplliance does not start or suddenly stops during operation.

## Cure

SYMPTOM: Aplliance does not start or suddenly stops during operation.

 $\ensuremath{\mathsf{INFO}}$  : The switch on the circuit board is open and might be melted somewhat.

CURE: Replace the complete circuit board service code 4322 006 23880

HISTORY: Symptom Cure SDA 75961

To prevent the switch getting damaged by too much force, a protective ring (pos. 53 or pos. 55) was added in the later versions.

If this part is missing it must still be placed as modification! Codenumber 4222 459 48641 Protective switch ring

See drawing in attachment