



Service information

Reference no.: SDA_96275

Symptom

New software for Exprelia Evo Class and Top

Cure

INFO:

Improvements in the functions and in the languages for the client in the Exprelia Evo Class and Top.

CURE:

Upload the new software V.01.00.09.

In detail:

Improved the visualization of the following sentences:

- "Please Wait" in Russian
- "Fill half carafe with water, Insert in Brew position" in Czech
- "Dbug" changed to "Debug" in the TEST mode

Very rarely at startup the CA took longer time to reach the ready temperature target and could happen E14 error (often after decalcification), it is now more responsive.

Aligned the Temperature performance between Ecomode ON and OFF.

Change the translations in the Russian language in the following sentences:

- "Latte Macchiato"
- "default"
- "low"
- "normal"
- "high"
- "minutes"

Tidy, on the lines available for text, the words making up the following five sentences in Greek:

- "Fill half carafe with water, Insert in Brew position"
- "Activate the filter?"
- "Step ½ decalcification"
- "Insert group clean tab"
- "Insert detergent into carafe and fill with water"