



Service information

Reference no.: GDA_111869

Symptom

Same HD for Exprelia Evo and Exprela EvoV2.

Cure

INFO:

Due to commercial reasons the HD codes for Exprelia Evo and Exprelia Evo V2 are the same. Only the 12NC linked to the HD changes.

CURE:

To identify the machine in the proper way, check the 12n as shown in the table below.

HD	12nc	DESCRIPTION	UP TO	FROM	
HD8858/01*	882885801010	EXPRELIA EVO2 TOP SS 230 EU	TU901515039226	TU901531095256	
HD8858/01	882885801020	EXPRELIA EVO2 TOP SS 230 EU		U901531095257	*
HD8859/01	882885901010	EXPRELIA EVO2 CLASS WH 230 EU	TU901516041387	TU901531095496	
HD8859/01**	882885901020	EXPRELIA EVO2 CLASS WH 230 EU		TU901531095497	*

*Red: OLD MACHINES (Exprelia Evo)

**Green: NEW MACHINES (Exprelia Evo 2)

Data label in the machine.



Exprelia Evo 2 - Main changes

* What's new / Important Exprelia Evo2 (HD8858/01-882885801020 & HD8859/01- 882885901020)	
Boiler	Boiler increased for greater water passage
Water container	New Water container for housing new filter
AquaClean water filter	New filter
Brew Unit	New Brew Unit with yellow components (The productions of October)

ADDITIONAL INFORMATION:

SERIAL NUMBER (First serial where solution has been implemented in production):

See table

IPM NUMBER (Philips Integrate Problem Management documentation reference number):

None

FAQ NUMBER (for Call Center reference):

None

INFORMATION FOR CALL CENTER:

None.

INFORMATION FOR CONSUMER:

None.

History:

28/10/2015 - Second Release - Image "Data label in the machine"

19/10/2015 - First Release