



Service information

Reference no.: SDA_109342

Symptom

Conveyor clogged by coffee powder in XSmall Vapore

Cure

INFO:

Piston component improved to solve the problem of conveyor occluded.

CURE:

Replace the piston, 11003077, 421941154921 (image1), with the new one, code: 421944025621 (image2).
(Image1) (Image2)



either replace the piston assy 11023086 (BLK 8GR.BREW UNIT NTEGR.PISTON GEN.ASSY.) with the new one 421944029791 (image4).

(Image3)

(Image4)



SERIAL NUMBER (First serial where solution has been implemented in production):

From TW901429419750

IPM NUMBER (Philips Integrate Problem Management documentation reference number):
None

FAQ NUMBER (for Call Center reference):
None

INFORMATION FOR SERVICE CENTER:
None

INFORMATION FOR CONSUMER:
None

HISTORY:
10/02/2015 - First Release