



Service information

Reference no.: SDA_79280

Symptom

Spring change on shaving unit

Cure

INFO:

we have only on service shaving units without spring.

CURE:

- 1*take the shaving unit from the shaver.
- 2*bring the spring in the position so it is in the closed position at the shaver.
- 3*push the yellow part to the above side of the spring
- 4*take the spring out of the unit
- 5*place the spring in the new unit
- 6*bring the spring in the shaver closed position
- 7*place the yellow part in the correct position
- 8*new shaving unit is complete