



Service information

Reference no.: SDA_87084

Symptom

New PCBA Quadrante non-SS has additional connector

Cure

INFO:

The spare PCBA for the Senseo Quadrante has been changed over to the PCBA which is also used in the Quadrante Strength Select (HD7862). There is full forward and backwards compatibility.

CURE:

The PCBA's are identical apart from an additional connector for the Strength Select button. When this connector is not plugged in (as would be the case for a regular Senseo Quadrante HD7860) the "normal" cup volume is selected. (when this connector would be short-circuited the "low" cup volume would be selected, which is not the case for a normal Senseo Quadrante.