



Service information

Reference no.: SDA_95338

Symptom

"New descaling process" in the Exprelia

Cure

INFO:
Improve the process of descaling.

CURE:
Starting from the new software V.01.08.02 the new descaling process has been implemented: now the descale solution clean also the pin of boiler.
Uploaded always the new software available in SSC.

Note:
When the machine is reprogrammed with new software, a descaling cycle must be done. The new software is going to reset all values and counters on the main board.

HISTORY:
23/05/2013 - Second review – Includes SDAs: 90856 - 90557.
25/10/2012 - First Release