



Service information

Reference no.: SDA_96483

Symptom

New software for Intelia Cappuccino with carafe sensors

Cure

INFO:
Improvements of descaling process in the Intelia Cappuccino with carafe sensors up to S/N TU901228113257

CURE:
Upload the new software V. 01.05.05 in the Intelia Cappuccino with carafe sensors up to S/N TU901228113257.

In detail:
Descaling cycle changed to pass descaling by valve group.
Bug fix count on steam descaling now counts double .
Test mode: introduced the voltage 230/120.