



Service information

Reference no.: SDA_98516

Symptom

New software for Exprelia Evo

Cure

INFO:

New software release to improve of the powder killer system and to update the descaling cycle.

CURE:

Upload the new software V. 01.03.06.

In Detail:

• **Powder Killer:**

Introduced the cleaning of the coffee powder every time a product (that involves the use of coffee), is stopped in an unexpected way.

• Additional useful changes was made on the descaling cycle:

1. Filling of the Coffee and Steam circuit before starting the phase 1 of the cycle.
2. Reduced the reaction time in order to speed up the cycle (from 60s to 50s for each pause).
3. Optimized the descale quantity in order to improve the performance of the process and minimize the descale wasting.